



- ① Remove clear wind deflector by unscrewing the same two T25 torx that hold the headlight guard brackets on. Clean the wind deflector with warm soapy water. Dry. Keep your hands clean.



- ② Attach sticker starting with the center ridge. The sticker is larger than the deflector and there should be some overhang on the edges. Press into the crosswise bend. Use your finger to press into place, pulling on the sticker edge with your other hand as necessary.



- ③ Continue to work from the center outward with your thumb or fingers, pressing out bubbles to the edge while lifting with your other hand. It may be lifted and repositioned as necessary to get it to lay smoothly. Large bubbles can be carefully pricked with a sharp exacto knife and pressed flat.



- ④ An old credit card can be used to help smooth it out, but careful as the sticker will tear with too much abuse. Wrap the excess around the edges. Re-install on the bike.