

Decal Placement Guide - BMW R 1200 GSW

R 1200 GSW Decal Kit - white

PN / ALTR-1-5306 - (x1)
PN / ALTR-1-5313 - (X2)
PN / ALTR-1-5308 - (X2)

R 1200 GSW Decal Kit - black

PN / ALTR-1-5305 (X1)
PN / ALTR-1-5314 (X2)
PN / ALTR-1-5308 (X2)



ALTRIDER

How to apply Decals.

1. **Prep the area. Clean the area with rubbing alcohol and ensure it is dry before applying the decal to the surface.**

2. **The decals are 3mil automotive grade vinyl. It is a tough and resilient material, but take care while applying, you can tear the decal if you are hasty.**

3. **Leave the decal in the premask and start by applying one corner of the vinyl. Slowly rub back and forth diagonally, applying pressure along the rest of the decal. This ensures no air gets trapped between the vinyl and the surface.**

Tip: If you end up with bubbles, use a little heat from a hair dryer to help push the bubbles down and/or out toward an edge.

One on the right of the beak.



8.5" Altrider Decal

One on the left of the beak.



8.5" Altrider Decal

One in the center of the beak.



A-logo Decal

One on the right of the tank shroud and a second on the left side.



Altrider logo Decal

