




AltRider Skid Plate for Honda Africa Twin INSTALLATION INSTRUCTIONS

The most up to date instructions can be downloaded from the product page at altrider.com, under the instructions tab.

Dear Rider,
Thank you for choosing AltRider! Whether a seasoned world adventurer or a first time ADV-Newbie, we welcome you to the AltRider experience. You can install your new product with the utmost confidence. AltRider designs, tests, and manufactures all of its products here in the United States. We are proud to do what we do, and honored to present to you the product of our labors.

Enjoy it, show it off, and most of all, RIDE IT!

Venture On,
Jeremy LeBreton



AltRider Skid Plate
Honda Africa Twin CRF1000L

Package Contents:
-Skid Plate
-Hardware
-Instructions

AltRider LLC

Global


mailing: 4000 Aurora Ave N Ste 100
Seattle, WA 98103 USA
phone: 206-922-3618
email: info@altrider.com
web: www.altrider.com

Europe

mailing: AltRider EU
Heliumstraat 230
2718 RS Zoetermeer
The Netherlands
email: info@altrider.eu
web: www.altrider.eu

REV 9.4
MADE IN THE USA





Kit:


- ① Skid plate
- ② Rear bracket
- ③ (2) M8 x 25 socket cap screws
- ④ (2) M8 washers
- ⑤ (4) M8 x 16 flat head screws
- ⑥ (4) Rubber adhesive strips




Required Tools:

- ① 12mm spanner
- ② 5mm allen tool
- ③ 6mm allen tool
- ④ 12mm socket
- ⑤ driver handle
- ⑥ ratchet handle
- ⑦ 14mm spanner
- ⑧ 14mm spanner
- ⑨ Medium strength thread locker







- ① Apply rubber adhesive strips on skid plate and on bracket.
 (A) Two strips go on bracket, one at right edge, one at left edge near flange.
 (B) Two strips go on skid plate, parallel to edge of welded rectangle as shown.



- ③ Remove rubber grommet from Honda belly pan and insert into AltRider rear bracket as shown. TIP! A dab of water will help it slide into place easier.




- ② Use 5mm allen wrench to remove the three M8 button head screws and remove OEM belly pan. You will not re-use these screws.




- ④ Use 12mm socket and remove the two hex head M8 screws from the small bracket as shown. Save these screws for reinstallation. Leave the OEM hose bracket in place.



- ⑤ Use two 14mm spanners to loosen the right rear frame bolt. If you have one spanner and one adjustable wrench, use the adjustable wrench to hold the bolt head stationary while using the spanner to loosen the nut. Remove the nut and save for reinstallation.




- ⑥ Install the AltRider rear bracket.
If you are also installing the AltRider Lower Crash Bars, pause this installation and move to installing the Lower Bars, they use these same mounting points.
 Slip the rubber grommet over the metal stud and the second hole onto the frame bolt. Thread the M10 nut back on the frame bolt finger tight.




- ⑦ Place the rear bracket over the small OEM hose routing bracket and reinstall the two M8 hex head screws finger tight.
! If you are also installing the AltRider Lower Crash Bars, pause this installation and move to installing the Lower Bars, they use these same mounting points.




- ⑧ Go back and tighten the M10 frame bolt completely (use two 14mm spanners or spanner + adjustable wrench).



- ⑨ Hold the AltRider skid plate in place and install the front two M8 cap head screws with washers. Apply a drop of thread locker to each screw. Just get the screws started, and leave loose during installation.



- ⑩ Attach skid to rear bracket, use four M8 flathead screws as shown. Apply a drop of loctite to each screw. Get each screw started by hand. Tighten each screw in sequence, working from screw to screw in turn until each is up to 10 Nm.



- ⑪ Tighten the two front M8 screws fully to 15 Nm.



- ⑫ Use 12mm spanner to fully tighten the two hex head bolts on the rear bracket as shown.

CONGRATULATIONS!

You've completed your installation. If at any point you have questions about your installation or have any feed back for us, we'd love to hear it. A downloadable version of these instructions can be found at our web site. www.AltRider.com

After 5 hours of riding, or 100 miles, check all the fasteners on the assembly to ensure they are tightened to spec.

Global Office:

email: info@AltRider.com
phone: +1 206-922-3618
address: 4000 Aurora Ave N
Ste 100
Seattle, WA 98103

Europe Office:

email: info@AltRider.eu
address: AltRider EU
Heliumstraat 230
2718 RS Zoetermeer
The Netherlands

TERMS OF USE, WARRANTY AND LIABILITY WAIVER

AltRider LLC, a Washington company, having its principal place of business in Seattle, WA ("AltRider") offers its motorcycle accessories (the "Product") with the terms, conditions and notices as follows:

Terms of Use

This Product is offered to you conditioned upon your acceptance without modification of the terms, conditions, and notices contained herein. Installation and/or use of this product implies acceptance of all such terms, conditions, and notices. If you do not agree to these terms, do not buy the Product. If you have already bought the Product and do not agree to these terms, return this Product promptly including the packaging and all written materials, to AltRider.

Limitation of Liability and Warranty Disclaimer

You may return your merchandise for a full refund or exchange, less any original or return shipping fees under these conditions:

1. Only if the merchandise is in 100% factory condition. Original manufacturer's packaging and same condition as sold – original boxes, packaging material, instructions, documentation, parts, and attached tags.
2. Only unused, unscratched, uninstalled, undamaged merchandise will be accepted. Do not install equipment until you are sure you want to keep it. Package items carefully in protective materials before returning them. Never ship an item in its original manufacturers packaging – it will arrive damaged. Please use a postal box or other adequate packaging to ensure your return or exchange is not damaged on the way back to AltRider.com.

To read more about our exchanges and returns policy, on the web, navigate to <http://www.altrider.com/info/exchangesAndReturns>

Excepting the warranties stated in the preceding paragraph, AltRider hereby disclaims all other warranties and conditions with regard to the Product including all implied warranties and conditions of merchantability and fitness for a particular purpose. There are no warranties which extend beyond the description on the face hereof. AltRider does not warrant against damages or defects arising out of use or installation of the Product. Installation instructions are provided for your convenience. AltRider is not responsible for any damages arising out of the installation, improper or otherwise, of the Product. No warranty of any kind, expressed or implied, is made regarding the safety of this Product.

To the extent allowed by law, AltRider shall not be held liable for any direct, indirect, punitive, incidental, special or consequential damages arising out of, or connected with, the use or misuse of this Product. Buyer assumes all risks and liability arising from use of this Product.

Entire Agreement

This document states the entire obligation of AltRider with respect to the Product. If any part of this agreement is determined to be void, invalid, unenforceable or illegal, including, but not limited to the warranty disclaimers and liability limitations set forth above, then the remainder of the agreement shall remain in full force and effect.

Applicable Law

This agreement is governed by the laws of Washington, USA. You hereby consent to the exclusive jurisdiction and venue of the courts of Washington, USA, in all disputes arising out of or relating to the use of this product.

