

Oil Cooler Guard for the 2015 Ducati Multistrada 1200

INSTALLATION INSTRUCTIONS

Dear Rider,
Thank you for choosing Altrider! Whether a seasoned world adventurer or a first time ADV-Newbie, we welcome you to the Altrider experience. You can install your new product with the utmost confidence. Altrider designs, tests, and manufactures all of its products here in the United States. We are proud to do what we do, and honored to present to you the product of our labors.

Enjoy it, show it off, and most of all, RIDE IT!

Venture On,
Jeremy LeBreton



Altrider Oil Cooler Guard for the Ducati Multistrada 1200

Package Contents:
- radiator guard
- instructions

Altrider LLC

Global

mailing: 4000 Aurora Ave N Ste 100
Seattle, WA 98103 USA
phone: 206-922-3618
email: info@altrider.com
web: www.altrider.com

Europe

mailing: Heliumstraat 230
2718 RS Zoetermeer
The Netherlands
email: info@altrider.eu
web: www.altrider.eu

Rev 1.0




**Kit:**

- ① Oil Cooler Guard
- ② paper instructions
- ③ Isopropyl Alcohol prep pad


**Recommended tools:**

- ① hardware bins (left and right)
- ② 1/4" driver
- ③ 3mm allen bit







- ① Remove the small black plastic cover surrounding the ignition switch (what used to be the key hole).




- ② Using a 3mm allen, remove all (4) of the fasteners indicated. There are 4 in total.




- ③ Remove the black plastic trim pieces on either side of the fairing. Use two handed pressure and slide the pieces forward to disengage the mounting tabs/slots.



- ④ Using a 3mm allen tool, remove the two screws on each side (4) in total. Note that these fasteners have small plastic washers on them, be sure to not lose any.



- ⑤ Using a 3mm allen tool, remove the (3) fasteners under the beak. Note: you may need to rotate the fork for best tool access.



- ⑥ Remove the black plastic under-beak. Take note of the rubber grommet, be sure this is in place correctly when you replace the black plastic part during re-assembly.




Air temp sensor wire.


- ⑦ Slide the entire beak forward about 1.5". Do not slide too far! There is a temp sensor wired from the main body to the beak, be careful not to damage this wire.



- ⑧ Practice inserting the oil cooler guard from below, you should have just enough clearance with the beak pulled out and tilted up slightly. Once you are confident with your placement, pull the guard out and peel off the backing from the VHB tape, insert from below and apply pressure to secure it.



- ⑨ Slide the beak rearward. Note there are two rubber grommets, ((1) left and (1) right) The beak has plastic tubes that insert into these grommets for correct positioning. Make sure the screw holes are aligned properly and that all of the plastic tabs overlap correctly.




- ⑩ Using a 3mm allen tool, reinstall the black under-nose piece (3 screws).




- ⑪ Using a 3mm allen tool, reinstall the (4) screws ((2) right and (2) left) that secure the beak to the rest of the fairing.



- ⑫ Reinstall black plastic "spears" Note there are 3 tabs/slots to line up. One at the very front near the nose openings, two on the side. Place in location and slide rearward with hand pressure.



- ⑬ Using a 3mm allen, reinstall all (4) of the fasteners indicated.



- ⑭ Replace the small black plastic cover surrounding the ignition switch (what used to be the key hole).

CONGRATULATIONS!

You've completed your installation. If at any point you have questions about your installation or have any feed back for us, we'd love to hear it. A downloadable version of these instructions can be found at our web site. www.AltRider.com

After 5 hours or 100 miles of riding, check your newly installed equipment to ensure all hardware is secure.

Global Office:

email: info@AltRider.com
phone: +1 206-922-3618
address: 4000 Aurora Ave N
Ste 100
Seattle, WA 98103

Europe Office:

email: info@AltRider.eu
address: Heliumstraat 230
2718 RS Zoetermeer
The Netherlands

TERMS OF USE, WARRANTY AND LIABILITY WAIVER

AltRider LLC, a Washington company, having its principal place of business in Seattle, WA ("AltRider") offers its motorcycle accessories (the "Product") with the terms, conditions and notices as follows:

Terms of Use

This Product is offered to you conditioned upon your acceptance without modification of the terms, conditions, and notices contained herein. Installation and/or use of this product implies acceptance of all such terms, conditions, and notices. If you do not agree to these terms, do not buy the Product. If you have already bought the Product and do not agree to these terms, return this Product promptly including the packaging and all written materials, to AltRider.

Limitation of Liability and Warranty Disclaimer

You may return your merchandise for a full refund or exchange, less any original or return shipping fees under these conditions:

1. Only if the merchandise is in 100% factory condition. Original manufacturer's packaging and same condition as sold – original boxes, packaging material, instructions, documentation, parts, and attached tags.
2. Only unused, unscratched, uninstalled, undamaged merchandise will be accepted. Do not install equipment until you are sure you want to keep it. Package items carefully in protective materials before returning them. Never ship an item in its original manufacturers packaging – it will arrive damaged. Please use a postal box or other adequate packaging to ensure your return or exchange is not damaged on the way back to AltRider.com.

To read more about our exchanges and returns policy, on the web, navigate to <http://www.altrider.com/info/exchangesAndReturns>

Excepting the warranties stated in the preceding paragraph, AltRider hereby disclaims all other warranties and conditions with regard to the Product including all implied warranties and conditions of merchantability and fitness for a particular purpose. There are no warranties which extend beyond the description on the face hereof. AltRider does not warrant against damages or defects arising out of use or installation of the Product. Installation instructions are provided for your convenience. AltRider is not responsible for any damages arising out of the installation, improper or otherwise, of the Product. No warranty of any kind, expressed or implied, is made regarding the safety of this Product.

To the extent allowed by law, AltRider shall not be held liable for any direct, indirect, punitive, incidental, special or consequential damages arising out of, or connected with, the use or misuse of this Product. Buyer assumes all risks and liability arising from use of this Product.

Entire Agreement

This document states the entire obligation of AltRider with respect to the Product. If any part of this agreement is determined to be void, invalid, unenforceable or illegal, including, but not limited to the warranty disclaimers and liability limitations set forth above, then the remainder of the agreement shall remain in full force and effect.

Applicable Law

This agreement is governed by the laws of Washington, USA. You hereby consent to the exclusive jurisdiction and venue of the courts of Washington, USA, in all disputes arising out of or relating to the use of this product.

